

POS. ITEM	° N°	CMF10NXX	CMF20NXX	CMF30NXX	CMF60NXX	CMF100N75
--------------	---------	----------	----------	----------	----------	-----------

1	1	K73FC				
2	1	ZTH010	ZTH020	ZTH030	ZTH060	ZTH100
* 3	1	300223106	300223150	300223168	300223256	300224375
4	2	-----	-----	---	3003510	3003512
5	2	-----	-----	-----	3004010	3004012
* 6	1	300222162	30413056	30413065	30413090	30413125
* 7	1	-----	-----	30327045	30327065	30327095
* 8	1	30410028	30410038	30410045	30410070	30410100
* 9	1	30405055	30405075	30405090	30405125	30405165
* 10	1	308233106	308233150	308233168	308233256	308234375
11	1	32010146	32020146	32030146	32060146	32100146
12	1	32010224XX	32020224XX	32030224XX	32060224XX	32100224075
13	1	32010234XX	32020234XX	32030234XX	32060234XX	32100234075
14	1	32010252XX	32020252XX	32030252XX	32060252XX	32100252075
15	1	32010260XX	32020260XX	32030260XX	32060260XX	32100260075

* KIT	MOD.	KCMF10N	KCMF20N	KCMF30N	KCMF60N	KCMF100N
-------	------	---------	---------	---------	---------	----------

ONLY/SOLO/NUR CMF20N50
300223150 + 308233150 no more necessary from S/N 11/04021
300223150 + 308233150 non necessari dal S/N 11/04021
300223150 + 308233150 nicht noetig von S/N 11/04021

Sostituire a XX le cifre corrispondenti alla corsa.
in relazione al modello. Es.: COURSA 075 (075 = 75 mm) per CMF100N75

Replace XX with the digits corresponding to the stroke
according to the model. Ex.: STROKE 075 (075 = 75 mm) for CMF100N75

Remplacer XX avec les chiffres correspondantes a' la course
par rapport au modele. Ex.: COURSE 075 (075 = 75 mm) pour CMF100N75

XX ersetzen durch Hub in Zoll des entsprechenden Zylindertyps.
Beispiel: HUB 075 (075 = 75mm) fuer CMF100N75

Sustituir XX por las cifras correspondientes a la carrera del modelo.
Ej: CARRERA 075 (075 = 75mm) para CMF100N75

Sobstituir XX com o valor do curso in relaao ao modelo.
Ex. CURSO 075 (075 = 75mm) por CMF100N75

